

ASSORTMENT SPECIAL

SAVE 30% ON GLADHAND SEALS!



GLADHANDS & REPLACEMENT SEALS

Air brake gladhands are coupling devices used to connect service lines (blue) and emergency air lines (red) from the truck or tractor to the trailer. The gladhand couplers have a rubber seal, which prevents air from escaping.

- **Eliminate leaks** at the gladhand by replacing gladhand seals when they are worn out.
- **When using colored seals, put the proper color in each type of gladhand connector.** Parking brake lines and fittings are red, while the service brakes are blue.
- **Wipe gladhand cavity clean** before installing new seal.
- **Rotate the seal several times** once it's in place to insure proper seating.



Gladhands

Assortment No. 826R



<p>393SER GLADHAND SERVICE</p> 	<p>393EME GLADHAND EMERGENCY</p> 	<p>393UNIV GLADHAND UNIVERSAL</p> 	<p>37535 LOCTITE DIELECTRIC GREASE 30Z TUBE</p> 
<p>394GLB GLADHAND SEAL SERVICE - BLUE</p> 	<p>394GLR GLADHAND SEAL EMERGENCY - RED</p> 	<p>394GL GLADHAND SEAL UNIVERSAL - BLACK</p> 	

GLADHANDS ASSORTMENT

IBS No. 826R • 6 Items • 22Pcs

NOW ONLY \$99⁹⁵

REGULARLY \$143²⁶ – SAVE \$43³¹

ALSO AVAILABLE INDIVIDUALLY



IBS No.	Description	PKG
393EME	GLADHAND EMERGENCY	1
393SER	GLADHAND SERVICE	1
393UNIV	GLADHAND UNIVERSAL	1
394GL	BLACK GLADHAND SEAL UNIVERSAL	10
394GLB	BLUE GLADHAND SEAL SERVICE	10
394GLR	RED GLADHAND SEAL EMERGENCY	10